

STICKER GUARD™

STICKER GUARD is an adhesive-backed, clear polymer film that protects the surface of your snowmobile from the direct application of tough-to-remove temporary decals.



1) APPLY THE DESIRED DECAL ONTO THE SURFACE OF THE STICKER GUARD...

STICKER GUARD IS EASY TO USE!

SIMPLY APPLY THE DESIRED TEMPORARY DECAL ONTO THE FRONT OF THE *STICKER GUARD*, PEEL AWAY THE RELEASE LINER, AND PLACE IT ONTO YOUR SNOWMOBILE. FOR REMOVAL, SIMPLY PEEL THE ENTIRE *STICKER GUARD* AWAY FROM THE MOUNTING SURFACE AND DISCARD.



UNIQUE DESIGN FOR EXTREME PERFORMANCE!

THE *STICKER GUARD* HAS BEEN SPECIFICALLY ENGINEERED FOR PERFORMANCE IN EXTREME COLD-WEATHER ENVIRONMENTS. IT OFFERS EXCELLENT ADHESION PROPERTIES TO -40 DEGREES F., AND CAN BE APPLIED TO A VARIETY OF SURFACES.

THE FLEXIBILITY OF THE *STICKER GUARD* ALLOWS IT TO EASILY CONFORM AROUND EDGES AND CONTOURS, PROVIDING FOR MULTIPLE PLACEMENT OPTIONS. IT IS THE PERFECT CHOICE FOR SNOWMOBILE HOODS AND WINDSHIELDS.

2) APPLY STICKER GUARD TO THE MOUNTING SURFACE...

EASY REMOVAL!

THE *STICKER GUARD* UTILIZES UNIQUE MATERIALS THAT ALLOW IT TO BE REMOVED WITHOUT TEARING APART OR LEAVING EXCESSIVE RESIDUE. UNLIKE TYPICAL DECALS, THIS RESULTS IN EASY REMOVAL WITH NO DAMAGE TO THE MOUNTING SURFACE.

AVAILABLE IN PACKAGES OF 10.



3) YOU'RE DONE! FOR REMOVAL, SIMPLY PEEL THE ENTIRE STICKER GUARD AWAY FROM SURFACE AND DISCARD.